

GM Lighting

Phone: (708) 478-0100, (866) 671-0811, Fax: (708) 478-2640 www.gmlighting.net

GM Lighting: LEDTask™: High Output, Standard Output Flexible LED Linear Ribbon and LED LightBar Hardwire Power Supply Installation Instructions.

For Models; LTH-2, LTH-4, LTH-8, LTH-16, LTH-25

Connect the LTW / LTW-WP Series Connectors to the DC output screw terminals located on the power supply making sure that the positive (+) from the LED ribbon is connected to the positive (+) screw terminal and the negative (-) from the LED ribbon to the negative (-) screw terminal. You will have two (2) sets or more of DC Output screw terminals depending on which power supply you have chosen for your installation. The larger wattage power supplies will offer more DC Output screw terminals. You can now connect your AC Input to the screw terminals clearly marked on the power supply. Ground – Neutral – Line. Please turn the power supply on at this time. If the ribbon does not light up, please check that all connections are correct polarity. Use these guidelines for the LED LightBar installations.

Consult NEC guidelines and your local codes.

